












BC30-PURE

Note: Always swab self-sealing port with sterile alcohol prior to accessing with a sterile syringe

<p>Step 1:</p>  <p>Draw 5mL of Citrate Anticoagulant into the 30mL Syringe.</p>	<p>Step 2:</p>  <p>Draw 25mL BMA into the syringe, filling each syringe to 30mL.</p>	<p>Step 3:</p>  <p>Filter the 30mL syringe into the 30mL syringe. Filter the BMA in the direction indicated on the filter.</p>	<p>Step 4:</p>  <p>Inject anticoagulated & filtered BMA into the Concentrating Device.</p>	<p>Step 5:</p> <p>Counterbalance and process the Concentrating Device at</p> <p>Executive Series Centrifuge 1 minute 4200 RPM</p> <p>Euro Series Centrifuge 2 minutes 3500 RPM</p>
<p>Step 5:</p>  <p>Aspirate the plasma into the 30mL syringe. Then aspirate 2mL of red blood cells into 3mL syringe.</p>	<p>Step 6:</p>  <p>Transfer the plasma and RBC into the Concentrating Accessory.</p>	<p>Step 7:</p> <p>Counterbalance and process the Concentrating Accessory at</p> <p>Executive Series Centrifuge 5 minutes 4200 RPM</p> <p>Euro Series Centrifuge 7 minutes 3500 RPM</p>	<p>Step 8:</p>  <p>Platelet buffycoat separates out at the bottom of the Concentrating Accessory.</p>	
<p>Step 9:</p>  <p>Aspirate plasma from the Concentrating Accessory. Leave 4mL of plasma.</p>	<p>Step 10:</p>  <p>Attach the 12mL syringe and swirl to resuspend the platelet buffycoat into the plasma.</p>	<p>Step 11:</p>  <p>Tilt to immerse the Aspirating Pipe into PureBMC®</p>	<p>Step 12:</p>  <p>Extract the PureBMC® PRP into the 12mL syringe.</p>	

