













GS120-PURE-II ** PLEASE DISCARD RED VENTED CAP FROM CONCENTRATING DEVICE BEFORE USE**

Note: Always swab self-sealing port with sterile alcohol prior to accessing with a ster

<p>Step 1:</p>  <p>Draw 6mL of Sodium Citrate Anticoagulant into each 60mL Syringe</p>	<p>Step 2:</p>  <p>Draw 54mL of whole blood into each syringe, filling each syringe to 60mL</p>	<p>Step 3:</p>  <p>Load the anticoagulated whole blood into each Concentrating Device <i>(Aspirate the residual blood in the line)</i></p>	<p>Step 4:</p>  <p>Place the Concentrating Devices in the centrifuge buckets at opposite ends and process at</p> <p>1.5 minutes 3800 RPM</p>
<p>Step 5:</p>  <p>Using each 60mL syringe, aspirate the platelet plasma suspension (PPS) from each device. Aspirate until the RBC fills the aspirating pipe. (It's normal to aspirate to aspirate small amounts of RBC into the syringe during this process)</p>	<p>Step 6:</p>  <p>Transfer the platelet plasma suspension (PPS) from each syringe into the Concentrating Accessory</p>	<p>Step 7:</p>  <p>Counterbalance and process the Concentrating Device at</p> <p>7 minutes 3800 RPM</p>	<p>Step 8:</p>  <p>Platelet Concentrate Buffycoat</p> <p>Platelet concentrate buffycoat separates out at the bottom of the Concentrating Accessory</p>
<p>Step 9:</p>  <p>Aspirate Platelet Poor Plasma Leave approximately 14mL</p> <p>Aspirate platelet poor plasma from the Concentrating Accessory Leave 14mL of plasma.</p>	<p>Step 10:</p>  <p>Attach the 20mL syringe and swirl to resuspend the platelet buffycoat into the plasma.</p>	<p>Step 11:</p>  <p>Tilt to immerse Aspirating Pipe into PurePRP®</p> <p>Tilt to immerse the Aspirating Pipe into the PurePRP®</p>	<p>Step 12:</p>  <p>14mL PurePRP®</p> <p>Extract the PurePRP® into the 20mL syringe</p>